



Description: 3rd Brake Light
Part Number: 531029

Application: 1999-2006 Chevy Silverado & 2007 Silverado Classic body style
/ 1999-2006 GMC Sierra &



Tools Needed: Phillips
screwdriver



Step 1: Locate the two phillips
screw and remove them with a
phillips screwdriver.



Step 2: Pull off the 3rd brake
light from the vehicle.



Step 3: Locate the wire
harness and unplug it from the
light.



Step 4: Take out the new Anzo
light and peel off the backing
from the blue resistor and
place inside the housing.



Step 5: Plug in the new Anzo
3rd brake light.



Step 6: Screw in the light
using the two phillips screw
removed from step 1.



Step 7: Test all functions
making sure everything works
before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

