



Description: Head Light
Part Number: 111067-111068
Application: 1994-2001 Dodge Ram



Tools needed. 10mm socket, flat head screwdriver.



Step 1: Use the flat head screwdriver to remove the pin holding in the place bumper



Step 2: Remove the plastic bumper guard.



Step 3: Remove the three push pins holding the dust cover from the frame.



Step 4: Remove the top 10mm screw holding in the headlight.



Step 5: Remove the second 10mm screw under the corner light.



Step 6: Remove the third screw from the bottom headlight.



Step 7: Twist off the corner light from the headlight.



Step 8: Unplug the headlight bulb from the housing.



Step 9: Remove the headlight from the car.



Step 10: Put in the new Anzo light and plug in the headlight harness.



Step 11: Plug in the corner light.



Step 12: Bolt on the headlight and check all functions before driving.



AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.