

DOWNLOAD ENHANCED INSTALL MANUALS AT dieselperformance.com



<u>BD Boost Fooler</u>

 Part #
 Application

 1515940
 2001-2004 Duramax LB7


Please read this manual before starting installation.

UNLESS AN EO# IS LISTED, THIS PRODUCT IS LEGAL IN CALIFORNIA FOR RACING VEHICLES ONLY, WHICH MAY NEVER BE USED UPON A HIGHWAY.

BD Engine Brake Inc. Plant Address: 33541 MacLure Rd. Abbotsford, BC, Canada V2S 7W2 U.S. Shipping Address: 88-446 Harrison St, Sumas, WA 98295 U.S. Mailing Address: P.O. Box 231, Sumas, WA 98295 Phone: 604-853-6096 | Fax: 604-853-8749 | Internet: www.bd-power.com

Installation

Locate the manifold pressure sensor, located on the top of the motor towards the passenger side. Refer to the picture below.



Unplug the factory harness from the boost pressure sensor. Plug the BD Boost Fooler inline with the MAP sensor and the factory harness.

Make sure to plug the factory harness into the BD Boost Fooler correctly (see picture below). The connector should lock (click) together, and not disconnect if pulled on. Do not connect the connector upside down.



Questions?

If you have any technical concerns or questions about this product, please contact our Technical Support hotline at (800) 887-5030, between 8:30 am - 5:30 pm Pacific Standard Time (PST).

BD Engine Brake Inc. Plant Address: 33541 MacLure Rd. Abbotsford, BC, Canada V2S 7W2 U.S. Shipping Address: 88-446 Harrison St, Sumas, WA 98295 U.S. Mailing Address: P.O. Box 231, Sumas, WA 98295 Phone: 604-853-6096 | Fax: 604-853-8749 | Internet: www.bd-power.com